
Exterior







^{*:} If equipped


^{*1:} For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

Interior






Interior




В



*: If equipped

Interior



Instrument panel


Turn si	ght switch P.191 Glove box ignal lever P.169 Power back door main switch P.204 switch P.57	P. 420
	Gauges and meters P.173 Multi-information display P.180	
B	A CLYPARS	65
	Engine (ignition) switch Windshield wiper and washer switch	P. 159 P. 207
	Rear window wiper and washer switch	P. 214
	Tilt and telescopic steering control switch	P. 90
	Parking brake pedal	P. 171
		P. 481
	*: If equippe	d

Instrument panel







▶ Without navigation system




^{*2:} Refer to "Navigation System Owner's Manual".

Instrument panel














^{*:} If equipped

P. 302

^{*1:} For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

^{*2:} Refer to "Navigation System Owner's Manual".

Luggage compartment

